



Aerospace Products For Down to Earth Comfort®

Oregon Aero® Zeta-C® Universal Helmet Upgrade Kit
Part Number: 95002

The Oregon Aero Zeta-C Universal Upgrade Kit can be used with the following equipment: Industrial Hard Hats, Firefighting Helmets, Surgeon's Head Lights, Face Shields, Welding Hoods, and Bump Caps.

Kit Includes: 2 Linear Pads(10" Long, 1.5" Wide), 1 Linear Pad(8.5" Long, 1.5" Wide), 4 Pieces of fastening material(6" Long, 1" Wide), and 2 Alcohol Pads.

Installation Instructions

1. Remove all existing foam or fabric padding from the headband and crown support from the equipment. For firefighting helmets, you will need to temporary remove or roll back the Nomex material that covers the suspension system in order to access the existing foam padding.
2. Adjust the headband and crown support sizing slightly larger.
3. Thoroughly clean the headband of any adhesive residue or other debris. Wipe down the plastic parts using the provided alcohol pads. Allow the alcohol to dry completely before moving on to the next step.
4. Apply one of the 2" pieces of adhesive backed hook-and-loop fastening material to the center of the front of the headband and another piece to the rear center of the headband. If the equipment has a hard plastic crown suspension, apply one of the 2" pieces to the center of it as well. If the crown suspension is made of nylon fabric, take two of the 2" hook-and-loop fastening material pieces and sandwich the nylon webbing between them by pressing the adhesive sides together with the nylon webbing in between them.
5. Only one side of the liner pads will adhere to the hook-and-loop fastening material. Identify the proper side of the liner pads and attach the center of the pad to the hook-and-loop material on the headband and install the 8-1/2" liner pad in the crown support.
6. Attach the remaining pieces of adhesive backed hook-and-loop along the head bands and crown support where the rest of the pads contact the plastic or nylon webbing to make a solid connection. Complete the installation by attaching the pads so they follow the contour of the suspension system. For firefighting helmets, re-install the Nomex material as was originally installed. Check for proper fit and adjust the suspension system and inner pads as necessary.

Cleaning Instructions

Clean liner pads by hand with a solution of mild soap and water. Rinse completely and allow to air dry. Never put pads in washing machine or dryer.

Satisfaction Guarantee

If you are not satisfied with your Oregon Aero product for any reason, you have 30 calendar days to return the product from the date you purchased it for a full refund or exchange. To be eligible, product must be in good condition and include the receipt.

Limited Warranty

This product is backed by a limited warranty against defects in manufacture for a period of two years from the date of purchase. In the event we receive the return of this product within the warranty period, and we agree that the product is defective, our sole obligation shall be to replace the product at no charge. We disclaim all other express or implied warranties, including any implied warranty of merchantability or fitness for a particular use. Some states do not permit the limitation of implied warranties, so this information may not apply to you.

Zeta-C® is a registered trademark of Oregon Aero, Inc

PKG-IN-035 Rev. 12192016

Oregon Aero, Inc.
34020 Skyway Drive, Scappoose OR 97056
www.oregonaero.com
customerservice@oregonaero.com

Phone: 800-888-6910
503-543-7399
Fax: 503-543-4820
Made in the U.S.A.